ROSCOMMON EQUIPMENT CENTER

Project Number 63 6x6 Wildland Fire Engines

April 2001



Design Packet 63E Protective Cabs for U.S. Military 2-1/2 Ton and 5 Ton 6x6 Trucks

National Association of State Foresters in Cooperation with Michigan's Forest Fire Experiment Station

Protective Cabs for U.S. Military 2-1/2 Ton and 5 Ton 6x6 Trucks

Introduction

Many excess vehicles come with a canvascovered driving compartment, or with no overhead operator protection at all. There are no guidelines or drawings readily available from the military for fabricating a protective cab. In the 1970's REC designed a steel cab for U.S. Military 6x6 trucks. It was recently refined and is documented here.

There are two styles of cabs found on the pre-1990's US military 6x6. Most 6x6's have cabs based on the U.S. Army Tank-Automotive Command "REO style" 2-1/2-ton and 5-ton units produced from the 1950's to 1980's. These vehicles were produced by several manufacturers through the years but the cab design was not changed. Often these trucks are referred to as the "REO-style" in reference to the REO Company which built the first of this style of 6x6. Note again that the cab is the same for either the 2-1/2-ton or 5-ton.

The 1950 Korean War vintage GMC 2-1/2-tons had a different cab. These trucks also had

unreliable automatic transmissions and are likely out of service. Because of this, we have not included GMC-style designs in this project.

How you make the cabs will depend on what skills and tools are available. These are not easy to craft. The bends we made conformed to the radius of dies we had. Some changes may be necessary to accommodate your resources. The manufacturing tolerances of the cab portion of these vehicles were not held tight. We have provided some places to make adjustment when installing the cab top to compensate for this. Be aware that getting the cab top, lower cab, and doors to align like they came from a modern factory will be difficult on some 6x6's. Each individual truck is a little different.

NOTE: The military ordered some 6x6's with hard tops. It is possible to find one to install. These tops are not as durable as REC's, but provide a less expensive alternative if available.

Procedure for Fabricating and Installing a Protective Cab on a "REO" Style 6X6 Truck

The finished cab will be similar in shape, to the truck's original canvas canopy. Remove the original canvas canopy and all fasteners that will interfere with the new steel protective cab.

The REO protective cab consists primarily of three 11 gauge steel panels, one piece of $2" \times 2" \times 1/8"$ angle iron, and two pieces of 1-1/4" x 1-1/4" x 1/8" angle iron. Each steel panel has two 90 degree bends of 2.5 inch radius near each end. The rough length of all three panels is 8 feet.

The panels are mitered to blend the bend radii as close as practical. We had 2.5 inch radius dies to make the bends. If you use another

radius, the dimensions will need adjusting to get a proper fit. Note that the radius of the bends in all the panels are the same. Because the radius is the same, the mitered corners of each panel blend making the fabrication easier. In order to do this, we chose not to match the shape of the lower cab which is not a true radius. Hence the rear cab mounting strip (35-0098) is sized to overhang the lower cab at the outer rear corners (Figure 1). We provide a sample hole pattern on the mounting strip, but this can be adjusted.




Figure 1 - View of lower rear cab corner from outside. Note the placement of closed-cell foam seals. The rear outside corners overhang so that we did not need to match the curve of the lower cab.

Tack weld the panels, mounting strip, angle, and tubing together using the lower cab for a fixture. It is wise to finish the welds at the upper rear mitered corner before the cab is removed. These welds will cause the cab top to clam if done off the fixture. The rest of the final welds will be easier if the cab top is removed. Remove the entire cab and weld all joints with a continuous weld inside and outside. Grind all outside welds smooth then prime and paint.

The wire guides provided for wire routing. Operators like to have a dome light for night use. A sample mount bracket is shown in the drawings. Both of these items are optional.




Figure 2 - View of inside left front corner showing the seal with the windshield frame, a cab top attachment bolt, and use of the wire guide for cabling.

After prime and painting, the top can be installed. Hard, closed cell foam seals are needed between the cab top and the top of the windshield as well as the rear lower cab. The seal thickness can be adjusted to shim the cab top to plumb.

Bolt the front of the cab top to the top of the windshield frame in five places (see Figure 2). Also bolt the rear of the top to the lower rear of the cab (see Figure 3).




Figure 3 - Inside lower right of cab top mounted to lower cab.

The adjustable window jam faces (00-1251, 00-1252) allow for the top to have fore-to-aft mounting adjustment. Install closed cell foam weatherstrips between the window and adjustable jam strips. The thickness of the foam will be determined by the gap.



Figure 4 - The rear of the REC cab showing a sliding rear window held in by typical window seal material. The sliding window adds ventilation when needed but is more expensive than fixed glass.


Install rear window (safety glass) by using rubber molding (see Figure 4). Local auto glass shops can help and will be able to supply glass and window molding. Molding should be precut and fitted to window opening before attempting to install glass.


When the cab is positioned on the truck for final installation, drill all additional holes and bolt it in place.

Tear drop shaped amber clearance/identification lights mount easily near the front edge of the cab top. These are one of the motor vehicle safety requirements for trucks of this size. The five 3-hole drill pattern shown in drawing 00-1248 is for mounting the lights. If a different style is used, add the appropriate holes.

Drawing List

Drawing Number	Drawing Name
35-0011C	Cab Top A/C
35-0010B	Windshield Gasket
35-0009B	Rear Cab Gasket
35-0008D	Cab Top W/C
28-8002B	Dome Light Mount
00-1258B	Dome Light Mount S/W
00-1257B	Dome Light Mount Tube
00-1256B	Front Angle S/W
00-1252B	Vertical Face
00-1251B	Horizontal Face
00-1250B	Vertical Tube
00-1249B	Horizontal Tube
00-1248D	Top Sheet
00-1247D	Upper Rear Panel
00-1246D	Rear Panel
00-1245C	Bottom Mtg. Strip
00-1244C	Front Angle
00-0164A	Wire Guide







PART NO:35-0010 MAT'L:RUBBER SHEETING, CLOSED CELL


NOTE: CUT FROM PART NO: 33-0028

STD. TOL.							DRAWN:	Γ
DECIMAL:								1
1 PLACE + - 0.06							CHECKED:	ı
								ı
ANGULAR:							APPROVED:	1⊢
+ - 1 DEG.	NO.	BY	DATE		REVISION			
DATE: 01/07/99	F	0	RE	ST	FIRE EXPERIMENT S	TA	NOITA	
SCALE: 1/8		Р	.O. I	30X	68 ROSCOMMON, MICHIGAN	4	8653	ľ
PROJECT NO.:	TI	TLE:	WIN	IDSF	HELD GASKET			C
	DECIMAL: 1 PLACE + - 0.06 2 PLACE + - 0.03 3 PLACE + - 0.05 ANGULAR: + - 1 DEC. DATE: 01/07/99 SCALE: 1/8	DECIMAL: 1 PLACE + - 0.06 2 PLACE + - 0.03 3 PLACE + - 0.005 ANGULAR: + - 1 DEG. NO. DATE: 01/07/99 SCALE: 1/8	DECIMAL: 1 PILAGE + - 0.06 2 PILAGE + - 0.03 3 PILAGE + - 0.005 ANGULAR: + - 1 DEG. NO. BY DATE: 01/07/99 SCALE: 1/8	DECIMAL: 1 PLACE + - 0.06 2 PLACE + - 0.03 3 PLACE + - 0.005 ANGULAR: + - 1 DEG. NO. BY DATE 01/07/99 SCALE: 1/8 P.O. E	DECIMAL: 1 PLACE + - 0.06 2 PLACE + - 0.03 3 PLACE + - 0.005 ANGULAR: + - 1 DEG.	DECIMAL: 1 PLACE + - 0.08 2 PLACE + - 0.03 3 PLACE + - 0.005 ANGULAR: + - 1 DEG. DATE: 01/07/99 FOREST FIRE EXPERIMENT S SCALE: 1/8 P.O. BOX 68 ROSCOMMON, MICHIGAN	DECIMAL: 1 PLACE + - 0.06 2 PLACE + - 0.03 3 PLACE + - 0.005 ANGULAR: + - 1 DEC. DATE: 01/07/99 FOREST FIRE EXPERIMENT STA SCALE: 1/8 P.O. BOX 68 ROSCOMMON, MICHIGAN 4	DECIMAL: 1 PLACE + - 0.06 2 PLACE + - 0.03 3 PLACE + - 0.005 ANGULAR: + - 1 DEC. DATE: 01/07/99 SCALE: 1/8 P.O. BOX 68 ROSCOMMON, MICHIGAN 48653









PART NUMBER: 28-8002

MAT'L: SHEET, 14 GA H R PICK & OILED


ASTM A569


FFES SPEC NO: AA-G1448AP

EST WT: 0.72 LBS

STD. TOLE	ERANCES						DRAWN: R.GREENLAW	
FRACTIC 0 TO 6 IN +	- 1/32						CHECKED:	MICHIGAN
6 IN AND UP DECIMAL:	+ - 1/16 ANGULAR:	_					KDB	DNR
1 PLACE + - 0.1 2 PLACE + - 0.01	+ - 1 DEG						APPROVED:	
3 PLACE + - 0.005		NO.	BY	DATE	REVISION			FOREST MANAGEMENT
FOF	REST		F	IR	E EXPERIMENT	STAT	ION	DIVISION
	Ρ.	0.	BO)	x 68	ROSCOMMON, MICHIGAN	48653		PROJECT NO.: 89-1
TITLE:	DC	M	E	L	GHT MOUNT	SCALE: 1 = 2	DATE: 24 FEB 93	DWG.28-8002B

ITEM	PART NO	DWG	DESCRIPTION	QTY	EST WT
1	28-8002	В	DOME LIGHT MOUNT	1	0.72
2	00-1257	А	DOME LIGHT MOUNT TUBE	1	0.62








PART NO: 00-1258 EST WT: 1.34 LBS

STD. TOL.					DRAWN:	1
DECIMAL:					DGP	- Command
1 PLACE + - 0.06 2 PLACE + - 0.03					CHECKED:	
3 PLACE + - 0.005 ANGULAR:					APPROVED:	
+ - 1 DEG.	NO.	BY	DATE	REVISION		1011/VIIS)
DATE: 03/10/99] F	Ol	RE	ST FIRE EXPERIMENT ST	TATION	FOREST MANAGMENT
SCALE: 1/2		Ρ	.O. I	30X 68 ROSCOMMON, MICHIGAN	48653	DIVISION
PROJECT NO.:	TI	TLE:	DO	ME LIGHT MOUNT S/W		DWG NO. 00-1258B









PART NO: 00-1252

MAT'L: SHEET,11 GA,4 X 8,HR P&O


ASTM A569


FFES SPEC NO: AA-G1148AP


EST WT: 0.68 LBS

Ī	STD. TOL.					DRAWN:						
-	DECIMAL: 1 PLACE + - 0.06					DGP CHECKED:						
١	2 PLACE + - 0.03 3 PLACE + - 0.005					CHECKED.						
١	ANGULAR:					APPROVED:						
ı	+ - 1 DEG.	NO.	BY	DATE	REVISION							
	DATE: 04/01/99	F	FOREST FIRE EXPERIMENT STA									
	SCALE: 1/4		Р	.O. E	80X 68 ROSCOMMON, MICHIGAN 48	3653						
	PROJECT NO.:	TI	TILE: VERTICAL FACE									









PART NO: 00-1250


MAT'L: TUBE, SQ 1-1/4 X 1-1/4 X 14 GA WA

G10100

FFES SPEC NO: AE-122501AL

EST WT: 2.12 LBS

STD. TOL.									DRAWN:	1
DECIMAL:										- The same of the
2 PLACE + - 0.03									CHECKED:	
									APPROVED:	L (*)
+ - 1 DEG.	NO.	BY	DATE			REVISION			,	
DATE:	\Box	\sim		CT FI				CT/	TION	/
		U	ベヒ	21 11	ベヒ	EXPE	ZIMENI	217	1101	FOREST MANAGMENT
SCALE: 1/4		Ρ	.O. I	30X 68	ROS	SCOMMON	, MICHIGAN	4	-8653	DIVISION
PROJECT NO .:	TIT	ΓLE:	VE	RTICAL	TUBE	•				DWG. 00-1250B
	DECIMAL: 1 PIACE + - 0.06 2 PIACE + - 0.03 3 PIACE + - 0.03 ANGULAR: + - 1 DEG. DATE: 04/01/99 SCALE: 1/4	DECIMAL: 1 PLACE + - 0.06 2 PLACE + - 0.03 3 PLACE + - 0.03 ANGULAR: + - 1 DEG. NO. DATE: 04/01/99 SCALE: 1/4	DECIMAL: 1 PLACE + - 0.06 2 PLACE + - 0.03 3 PLACE + - 0.005 ANGULAR: + - 1 DEG. NO. BY DATE: 04/01/99 SCALE: 1/4	DECIMAL: 1 PLACE + - 0.06 2 PLACE + - 0.03 3 PLACE + - 0.03 3 PLACE + - 0.005 ANGULAR: + - 1 DEC. 04/01/99 SCALE: 1/4 P.O. I	DECIMAL: 1 PLACE + - 0.06 2 PLACE + - 0.03 3 PLACE + - 0.005 ANGULAR: + - 1 DEG. DATE: 04/01/99 SCALE: 1/4 P.O. BOX 68	DECIMAL: 1 PLACE + - 0.06 2 PLACE + - 0.03 3 PLACE + - 0.03 3 PLACE + - 0.005 ANGULAR: + - 1 DEG. DATE: 04/01/99 SCALE: 1/4 P.O. BOX 68 ROS	DECIMAL: 1 PLACE + - 0.06 2 PLACE + - 0.03 3 PLACE + - 0.005 ANGULAR: + - 1 DEG. NO. BY DATE REVISION DATE: 04/01/99 SCALE: 1/4 P.O. BOX 68 ROSCOMMON	DECIMAL: 1 PLACE + - 0.06 2 PLACE + - 0.06 3 PLACE + - 0.005 ANGULAR: + - 1 DEC. DATE: 04/01/99 SCALE: 1/4 P.O. BOX 68 ROSCOMMON, MICHIGAN	DECIMAL: 1 PLACE + - 0.06 2 PLACE + - 0.03 3 PLACE + - 0.03 3 PLACE + - 0.005 ANGULAR: + - 1 DEG. DATE: 04/01/99 FOREST FIRE EXPERIMENT STA SCALE: 1/4 P.O. BOX 68 ROSCOMMON, MICHIGAN 4	DECIMAL: 1 PIAGE + - 0.06 2 PIAGE + - 0.03 3 PIAGE + - 0.005 ANGULAR: + - 1 DEG. DATE: 04/01/99 SCALE: 1/4 P.O. BOX 68 ROSCOMMON, MICHIGAN 48653



PART NO: 00-1249

MAT'L: TUBE, SQ 1-1/4 X 1-1/4 X 14 GA WA

G10100

FFES SPEC NO: AE-122501AL

EST WT: 3.28 LBS

	STD. TOL.								DRAWN:	1
ı	DECIMAL:								DGP	- The same
١	1 PLACE + - 0.06 2 PLACE + - 0.03								CHECKED:	
ŀ	3 PLACE + - 0.005 ANGULAR:								APPROVED:	
١	+ - 1 DEG.	NO.	BY	DATE		REVISION				W V
ı	DATE:		\sim	\neg	CT LID		DIMENT	CTA	TION	תוואוושן
١	04/01/99		U	KE	21 FIK	E EXPE	RIMENT	SIF	VOIV	FOREST MANAGMENT
	SCALE: 1/4		Ρ	.O. I	30X 68	ROSCOMMON	N, MICHIGAN	4	-8653	DIVISION
	PROJECT NO .:	TI	ΓLE:	HC	RIZONTAL	TUBE				DWG. 00-1249B
_		_								

